

CUSTOM SHOCKS

SHOCKS FOR CUSTOM OFF-ROAD USE ONLY

RS5000™ SERIES / RS9000™XL SERIES

PART No.	PART No.	MOUNTING CODES		LENGTHS		
		Upper	Lower	Compressed	Extended	Travel
-	RS999028	L1	L1	17.25	27.96	10.71
RS55012	RS999012	L1	L1	19.01	32.54	13.53
RS55034	RS999034	L1	L1	20.01	34.04	14.03
RS55036	RS999036	L1	L1	21.01	36.04	15.03

RS7000® MT SERIES

PART No.	MOUNTING CODES		LENGTHS		
	Upper	Lower	Compressed	Extended	Travel
RS7008	L1	L1	14.00	21.470	7.46
RS7034	L1	L1	20.81	33.63	12.81
RS7112	L1	L1	16.25	25.88	9.63
RS7118	L1	L1	14.26	22.31	8.06
RS7391	S51	L1	12.33	19.01	6.68



REPLACEMENT URETHANE SHOCK BUSHING

BUSHING KIT	PARTS PACK	MOUNTING CODE	DESCRIPTION
RS980	-	L1	5/8-in. Straight wall bushing
RS978	-	L1	5/8-in. Hour glass bushing
RS992	-	L2	11/16-in. Straight wall bushing
RS984	-	L3	3/4-in. Hour glass bushing
-	P01192	S42	3/8-in. - 16 Stem
-	P01356	S51	1/2-in. - 13 Stem

SHOCK BOOTS

PART No.	LENGTH	COLOR
RS1927	9.50	Red
RS1950	9.50	Blue
RS1951	9.50	Yellow
RS1952	9.50	Black
RS1937	12.50	Red

