

CONTROL ARM SKID PLATE KIT RS6210

READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION

Parts List

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
176480	Control Arm Skid Plate	2
860605	Hardware Kit	1
	Spacer	4
	M14-2.00 x 120	2
	M14-2.00 Stover Nut	2
	M14 Washer	4
88610	Instruction	1



Note: This kit will not fit on vehicles equipped with alignment cams.

- 1) Support lower control arm. Remove axle bracket nut and bolt.
- 2) Position skid plate 176480 over axle bracket. Place tab over bracket lip and align mounting holes.
- 3) Insert a spacer on each side of the bracket. Attach skid plate and control arm to the axle bracket with the supplied hardware.
- 4) Tighten nut and bolt to 130 ft. lbs.
- 5) Repeat for other side.

