



quickLIFT™ Loaded

Year	Model	Raised Height		quickLIFT™		
		Front	Rear	Front	Rear	
CHEVROLET						
Avalanche - 4WD						
2013-07	All; w/ Air Leveling System; w/ Z55 Autoride Suspension	2"	0"	RS999928	—	
	All; w/o Air Leveling System; w/o Electronic Suspension; w/o GM Auto Track System; w/o Z71 Off Road Package	2"	¾"	RS999901	—	
	Shock Absorber			—	RS999262	
	Coil Spring Spacer Kit			—	RS70075 ^[254]	
Avalanche - 2WD						
2013-07	All; w/ Air Leveling System; w/ Electronic Suspension; w/ GM Auto Track System	2"	0"	RS999928	—	
	All; w/o Air Leveling System; w/o Electronic Suspension; w/o GM Auto Track System; w/o Z71 Off Road Package	2"	¾"	RS999901	—	
	Shock Absorber			—	RS999262	
	Coil Spring Spacer Kit			—	RS70075 ^[254]	
Colorado - 4WD						
2022-15	All; w/o ZR2	Left Right Shock Absorber	1¾"	0"	RS999952	—
					RS999951	—
					—	RS999023
					—	RS999023
Colorado - 2WD						
2022-15	All;	Left Right Shock Absorber	1¾"	0"	RS999952	—
					RS999951	—
					—	RS999023
					—	RS999023
Pickup — Silverado 1500 1/2 Ton - 4WD						
2022-20	All; Exc. Custom Trail Boss & LT Trail Boss Submodel w/ Z7X Suspension, ZR2, Standard Cab Models, 4 Cylinder Engines, High Country Models w/ Adaptive Control Suspension	Shock Absorber	2"	0"	RS999950	—
					—	RS999198
2022-19	Custom Trail Boss & LT Trail Boss Submodels; Exc. ZR2, 4 Cylinder Engines	Shock Absorber	0"	0"	RS999950	—
					—	RS999269
2019	All; New Body Style; Exc. Custom Trail Boss & LT Trail Boss Submodel w/ Z7X Suspension; Standard Cab Models, 4 Cylinder Engines	Shock Absorber	2"	0"	RS999950	—
					—	RS999198
2018-14	All w/o High Country; w/o Electronic Suspension; w/o ZW7 Smooth Ride Suspension	Shock Absorber	2"	0"	RS999949	—
					—	RS999198
2013-07	All; w/o Electronic Suspension; w/o 4 Wheel Steering; w/o ZW7 Self-Leveling Nivomat Suspension	Shock Absorber	2"	0"	RS999901	—
					—	RS999198
Pickup — Silverado 1500 LTD 1/2 Ton - 4WD						
2022	All; Exc. Custom Trail Boss & LT Trail Boss Submodel w/ Z7X Suspension, ZR2, Standard Cab Models, 4 Cylinder Engines, High Country Models w/ Adaptive Control Suspension	Shock Absorber	2"	0"	RS999950	—
					—	RS999198
	Custom Trail Boss & LT Trail Boss Submodels; Exc. ZR2, 4 Cylinder Engines	Shock Absorber	0"	0"	RS999950	—
					—	RS999269
Pickup — Silverado 1500 LD 1/2 Ton - 4WD						
2019	Silverado 1500 LD; Old Body Style;	Shock Absorber	2"	0"	RS999949	—
					—	RS999198

^[254] Rear kit, required to level the rear to the front height.

quickLIFT™ Loaded



Year	Model	Raised Height		quickLIFT™	
		Front	Rear	Front	Rear
CHEVROLET					
Pickup — Silverado 1500 1/2 Ton - 2WD					
2022-20	All; New Body Style Exc. Standard Cab Models, 4 Cylinder Engines, High Country Models w/ Adaptive Control Suspension	2"	0"	RS999950	—
	Shock Absorber			—	RS999198
2019	All; New Body Style; Exc. Standard Cab Models, 4 Cylinder Engines, Trailboss Models	2"	0"	RS999950	RS999198
2018-07	All; w/o Electronic Suspension; w/o 4 Wheel Steering; w/o ZW7 Self-Leveling Nivomat Suspension	2"	0"	RS999901	—
Pickup — Silverado 1500 LTD 1/2 Ton - 2WD					
2022	All; New Body Style Exc. Standard Cab Models, 4 Cylinder Engines, High Country Models w/ Adaptive Control Suspension	2"	0"	RS999950	—
	Shock Absorber			—	RS999198
Pickup — Silverado 1500 LD 1/2 Ton - 2WD					
2019	All; Old Body Style;	2"	0"	RS999901	—
	Shock Absorber			—	RS999198
Suburban — 1500 1/2 Ton - 4WD					
2019-15	All; w/o Z95 Magnetic Ride Control Suspension; w/o Z85 Self-Leveling Rear Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
2014-07	All; w/ Air Leveling System; w/ Electronic Suspension; w/ GM Auto Track System	2"	0"	RS999928	—
	All; w/o Air Leveling System; w/o Electronic Suspension; w/o GM Auto Track System; w/o Z71 Off Road Package	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
Suburban — 1500 1/2 Ton - 2WD					
2019-15	All; w/o Z95 Magnetic Ride Control Suspension; w/o Z85 Self-Leveling Rear Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
2014-07	All; w/ Z55 Autoride Suspension	2"	0"	RS999928	—
	All; w/o Air Leveling System; w/o Electronic Suspension; w/o GM Auto Track System; w/o Z71 Off Road Package	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
Tahoe - 4WD					
2019-15	All; w/o Z95 Magnetic Ride Control Suspension; w/o Z85 Self-Leveling Rear Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
2014-07	All; w/o Z55 Autoride Suspension; Exc. Hybrid	2"	0"	RS999928	—
	All; Exc. AWD, Hybrid; w/o Air Leveling System; w/o Z71 Off Road Package; w/o ZW7 Self-Leveling Nivomat Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]

^[254] Rear kit, required to level the rear to the front height.



quickLIFT™ Loaded

Year	Model	Raised Height		quickLIFT™	
		Front	Rear	Front	Rear
CHEVROLET					
Tahoe - 2WD					
2019-15	All; w/o Z95 Magnetic Ride Control Suspension; w/o Z85 Self-Leveling Rear Suspension Shock Absorber Coil Spring Spacer Kit	2"	¾"	RS999901	—
				—	RS999262
				—	RS70075 ^[254]
2014-07	All; w/ Air Leveling System; w/ Electronic Suspension; w/ GM Auto Track System; w/ ZW7 Self-Leveling Nivomat Suspension; Exc. Hybrid All; Exc. Hybrid; w/o Air Leveling System; w/o Electronic Suspension; w/o GM Auto Track System; w/o ZW7 Self-Leveling Nivomat Suspension Shock Absorber Coil Spring Spacer Kit	2"	0"	RS999928	—
				—	RS999262
				—	RS70075 ^[254]
DODGE/RAM					
Pickup — Ram 1500 1/2 Ton - 4WD					
2022-19	Ram 1500 (DT Body Code) (New Body Style); Gas or Flex Fuel Engines Only; w/o Air Suspension, w/o Off-Road Package, w/o Rebel Left Right Shock Absorber	2"	0"	RS999954	—
				RS999953	—
				—	RS999072
2018-09	All; Gas or Flex Fuel Engines Only; Exc. TRX; w/o Air Suspension; w/o Rebel Left Right Shock Absorber	2"	0"	RS999944	—
				RS999930	—
				—	RS999367
2008-06	All; Exc. TRX; w/o Mega Cab Left Right Shock Absorber	1½"	0"	RS999943	—
				RS999929	—
				—	RS999274
2007-06	TRX; w/o Mega Cab Left Right Shock Absorber	1"	0"	RS999943	—
				RS999929	—
				—	RS999274
Pickup — Ram 1500 Classic 1/2 Ton - 4WD					
2022-19	Ram 1500 Classic (DS Body Code)(Old Body Style); Gas or Flex Fuel Engines Only; w/o Air Suspension Left Right Shock Absorber	2"	0"	RS999944	—
				RS999930	—
				—	RS999367
Pickup — Ram 1500 1/2 Ton - 2WD					
2022-19	Ram 1500 (DT Body Code) (New Body Style); Gas and Flex Engines Only; w/o Air Suspension, w/o Rebel Left Right Shock Absorber	2"	0"	RS999954	—
				RS999953	—
				—	RS999072

^[254] Rear kit, required to level the rear to the front height.

quickLIFT™ Loaded



Year	Model	Raised Height		quickLIFT™		
		Front	Rear	Front	Rear	
FORD						
Expedition - 4WD						
2012-07	All; w/o Air Suspension and EL	Left Right Rear	1¼"	¾"	RS999940	—
					RS999925	—
					—	RS999926
2006-03	All; w/o Air Suspension	Left Right	1"	¾"	RS999932	RS999933
					RS999902	RS999903
Expedition - 2WD						
2012-07	All; w/o Air Suspension and EL	Left Right Rear	1¼"	¾"	RS999940	—
					RS999925	—
					—	RS999926
2006-03	All; w/o Air Suspension	Left Right	1"	¾"	RS999932	RS999933
					RS999902	RS999903
Explorer - 4WD						
2010-06	All; w/ 4.0 Liter V6	Left Right	1¾"	1"	RS999939	RS999942
					RS999924	RS999927
	All; w/ 4.6 Liter V8	Left Right	1"	1"	RS999939	RS999942
					RS999924	RS999927
Explorer - 2WD						
2010-06	All; w/ 4.0 Liter V6	Left Right	1¾"	1"	RS999939	RS999942
					RS999924	RS999927
	All; w/ 4.6 Liter V8	Left Right	1"	1"	RS999939	RS999942
					RS999924	RS999927
Pickup — F100, F150 Series 1/2 Ton - 4WD						
2020-15	All; Exc. Raptor, 3.0L Diesel Engine	Left Right Shock Absorber	2¾"	0"	RS999946	—
					RS999945	—
					—	RS999316
2014	All; Exc. Harley-Davidson, SVT Raptor, 6.2L Engine; AWD; w/o 8,200lb GVW	Left Right Shock Absorber	2"	0"	RS999946	—
					RS999945	—
					—	RS999384
2013-09	All; Exc. Harley-Davidson, SVT Raptor, 6.2L Engine; AWD; w/o 8,200lb GVW	Left Right Shock Absorber	2"	0"	RS999935	—
					RS999911	—
					—	RS999384
2008-04	All; Exc. AWD; w/o 8,200lb GVW	Shock Absorber	2½"	0"	RS999910	—
					—	RS999286



quickLIFT™ Loaded

Year	Model	Raised Height		quickLIFT™		
		Front	Rear	Front	Rear	
FORD						
Pickup — F100, F150 Series 1/2 Ton - 2WD						
2020-14	All; Exc. Std. Cab, Diesel	Left Right Shock Absorber	2.25"	0"	RS999948	—
					RS999947	—
					—	RS999149
2013-09	All; Exc. 6.2L Engine	Left Right Shock Absorber	1¾"	0"	RS999936	—
					RS999912	—
					—	RS999286
2008-04	All		1¾"	0"	RS999909	RS999285
GMC						
Canyon - 4WD						
2022-15	All	Left Right Shock Absorber	1¾"	0"	RS999952	—
					RS999951	—
					—	RS999023
Canyon - 2WD						
2022-15	All	Left Right Shock Absorber	1¾"	0"	RS999952	—
					RS999951	—
					—	RS999023
Pickup — Sierra 1500 1/2 Ton - 4WD						
2022-20	All; Exc. AT4, AT4X, Denali, Standard Cab Models, 4 Cylinder Engines	Shock Absorber	2"	0"	RS999950	—
					—	RS999198
2022-19	AT4 Models; Exc. Denali, AT4X, 4 Cylinder Engines	Shock Absorber	0"	0"	RS999950	—
					—	RS999269
2019	All; New Body Style: Exc. AT4 w/ Z7X Suspension and Denali submodels w/ Z45 Adaptive Ride Control; Standard Cab Models, 4 Cylinder Engines	Shock Absorber	2"	0"	RS999950	—
					—	RS999198
2018-14	All w/o Denali; w/o Electronic Suspension; w/o ZW7 Smooth Ride Suspension	Shock Absorber	2"	0"	RS999949	—
					—	RS999198
2013-07	All; Exc. AWD; w/o Electronic Suspension; w/o 4 Wheel Steering; w/o ZW7 Self-Leveling Nivomat Suspension	Shock Absorber	2"	0"	RS999901	—
					—	RS999198
Pickup — Sierra 1500 Limited 1/2 Ton - 4WD						
2022	All; Exc. AT4, Denali, Standard Cab Models, 4 Cylinder Engines	Shock Absorber	2"	0"	RS999950	—
					—	RS999198
	AT4 Models; Exc. Denali, 4 Cylinder Engines	Shock Absorber	0"	0"	RS999950	—
					—	RS999269
2019	Sierra 1500 Limited; Old Body Style	Shock Absorber	2"	0"	RS999949	—
					—	RS999198
Pickup — Sierra 1500 1/2 Ton - 2WD						
2022-20	All; Exc. Standard Cab; 4 cylinder engines, Denali	Shock Absorber	2"	0"	RS999950	—
					—	RS999198
2019	All; New Body Style: Exc. Standard Cab; 4 cylinder engines	Shock Absorber	2"	0"	RS999950	—
					—	RS999198

quickLIFT™ Loaded



Year	Model	Raised Height		quickLIFT™	
		Front	Rear	Front	Rear
GMC					
Pickup — Sierra 1500 1/2 Ton - 2WD (Cont.)					
2018-07	All; w/o Electronic Suspension;	2"	0"	RS999901	—
	Shock Absorber			—	RS999198
Pickup — Sierra 1500 Limited 1/2 Ton - 2WD					
2022	All; Exc. Denali, Standard Cab Models, 4 Cylinder Engines	2"	0"	RS999950	—
	Shock Absorber			—	RS999198
2019	All; Old Body Style; w/o Electronic Suspension;	2"	0"	RS999901	—
	Shock Absorber			—	RS999198
Yukon - 4WD					
2019-15	All; w/o Z95 Magnetic Ride Control Suspension; w/o Z85 Self-Leveling Rear Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
2013-07	All; w/ Z55 Autoride Suspension	2"	0"	RS999928	—
	All; w/o Air Leveling System; w/o Electronic Suspension; w/o GM Auto Track System; w/o Z71 Off Road Package; w/o ZW7 Self-Leveling Nivomat Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
Yukon - 2WD					
2019-15	All; w/o Z95 Magnetic Ride Control Suspension; w/o Z85 Self-Leveling Rear Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
2013-07	All; w/ Z55 Autoride Suspension	2"	0"	RS999928	—
	All; w/o Air Leveling System; w/o Electronic Suspension; w/o GM Auto Track System; w/o Z71 Off Road Package; w/o ZW7 Self-Leveling Nivomat Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
Yukon XL 1500 - 4WD					
2019-15	All; w/o Z95 Magnetic Ride Control Suspension; w/o Z85 Self-Leveling Rear Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
2014-07	All; w/ Z55 Autoride Suspension; Exc. AWD	2"	0"	RS999928	—
	All; w/o Air Leveling System; w/o Electronic Suspension; w/o GM Auto Track System; w/o Z71 Off Road Package; w/o ZW7 Self-Leveling Nivomat Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
Yukon XL 1500 - 2WD					
2019-15	All; w/o Z95 Magnetic Ride Control Suspension; w/o Z85 Self-Leveling Rear Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]
2014-07	All; w/ Z55 Autoride Suspension	2"	0"	RS999928	—
	All; w/o Air Leveling System; w/o Electronic Suspension; w/o GM Auto Track System; w/o Z71 Off Road Package; w/o ZW7 Self-Leveling Nivomat Suspension	2"	3/4"	RS999901	—
	Shock Absorber			—	RS999262
	Coil Spring Spacer Kit			—	RS70075 ^[254]

^[254] Rear kit, required to level the rear to the front height.



quickLIFT™ Loaded

Year	Model	Raised Height		quickLIFT™	
		Front	Rear	Front	Rear
INFINITI					
QX56					
2011-04	All		1¾"	1¾"	
		Left			RS999937
		Right			RS999921
		Shock Absorber			—
		Coil Spring Spacer Kit			RS999113
					—
					RS70077 ^[254]
LINCOLN					
Mark LT - 4WD					
2008-06	All; w/o 8,200lb GVW		1½"	0"	RS999910
		Shock Absorber			—
					RS999286
Mark LT - 2WD					
2008-06	All		1¾"	0"	RS999909
		Shock Absorber			—
					RS999285
MERCURY					
Mountaineer - 4WD					
2010-06	All		1¾"	1"	
		Left			RS999939
		Right			RS999924
					RS999942
					RS999927
Mountaineer - 2WD					
2010-06	All		1¾"	1"	
		Left			RS999939
		Right			RS999924
					RS999942
					RS999927
NISSAN					
Armada					
2015-05	All; w/o Rear Leveling System		1¾"	1¾"	
		Left			RS999937
		Right			RS999921
		Shock Absorber			—
		Coil Spring Spacer Kit			RS999306
					—
					RS70077 ^[254]
Frontier - 4WD					
2019-05	All; Exc. Nismo & Pro-4x		2"	0"	RS999922
		Shock Absorber			—
					RS999311
Frontier - 2WD					
2019-05	All		2"	0"	RS999922
		Shock Absorber			—
					RS999311
Pathfinder - 4WD					
2012-05	All		2"	1¾"	RS999922
		Shock Absorber			—
		Coil Spring Spacer Kit			RS999312
					—
					RS70077 ^[254]

^[254] Rear kit, required to level the rear to the front height.

quickLIFT™ Loaded



Year	Model	Raised Height		quickLIFT™		
		Front	Rear	Front	Rear	
NISSAN						
Pathfinder - 2WD						
2012-05	All		2"	1¾"	RS999922	—
					—	RS999312
					—	RS70077 ^[254]
Titan - 4WD						
2019-17	All; Exc. PRO-4X; w/o Off Road Package		1¾"	0"		
		Left			RS999937	—
		Right			RS999921	—
		Rear			—	RS999054
2015-04	All; Exc. PRO-4X; w/o Off Road Package		1¾"	0"		
		Left			RS999937	—
		Right			RS999921	—
		Shock Absorber			—	RS999303
Titan - 2WD						
2019-17	All; Exc. PRO-4X; w/o Off Road Package		1¾"	0"		
		Left			RS999937	—
		Right			RS999921	—
		Shock Absorber			—	RS999054
2015-04	All; Exc. PRO-4X; w/o Off Road Package		1¾"	0"		
		Left			RS999937	—
		Right			RS999921	—
		Shock Absorber			—	RS999303
Xterra - 4WD						
2015-05	All		1¾"	1½"	RS999922	—
		Shock Absorber			—	RS999314
		Leaf Helper Spring			—	RS70078 ^[254]
Xterra - 2WD						
2015-05	All		1¾"	1½"	RS999922	—
		Shock Absorber			—	RS999313
		Leaf Helper Spring			—	RS70078 ^[254]
TOYOTA						
4Runner						
2020-03	All; w/o Delphi REAS Suspension System, Kinetic Dynamic Suspension System		2"	1½"		
		Left			RS999913	—
		Right			RS999914	—
		Shock Absorber			—	RS999305
		Coil Spring Spacer Kit			—	RS70080 ^[254]
FJ Cruiser						
2014-07	All		2"	1½"		
		Left			RS999913	—
		Right			RS999914	—
		Shock Absorber			—	RS999305
		Coil Spring Spacer Kit			—	RS70080 ^[254]

^[254] Rear kit, required to level the rear to the front height.



quickLIFT™ Loaded

Year	Model	Raised Height		quickLIFT™	
		Front	Rear	Front	Rear
TOYOTA					
Sequoia					
2007-01	All				
		2¼"	1¾"		
	Left			RS999923	—
	Right			RS999931	—
	Coil Spring Spacer Kit			—	RS70081 ^[254]
Tacoma - 4WD					
2019-05	All; Exc. TRD Pro				
		2½-3"	1½"	RS999915	—
	Shock Absorber			—	RS999319
	Rear Block Kit				RS70901 ^[254]
2004-95	All				
		1¾"	0"		
	Left			RS999907	—
	Right			RS999908	—
	Left Shock Absorber			—	RS999226
	Right Shock Absorber			—	RS999180
Tacoma - 2WD					
2019-16	All				
		1¾"	1½"	RS999915	—
	Shock Absorber			—	RS999319
	Rear Block Kit				RS70901 ^[254]
2015-05	Pre Runner				
		1¾"	1½"	RS999915	—
	Shock Absorber			—	RS999319
	Rear Block Kit				RS70901 ^[254]
2004-98	Pre Runner				
		1¾"	0"		
	Left			RS999907	—
	Right			RS999908	—
	Left Shock Absorber			—	RS999226
	Right Shock Absorber			—	RS999180
Tundra - 4WD					
2019-07	All; w/o Crew Max or TRD Pro Package				
		2¼"	0"		
	Left			RS999919	—
	Right			RS999920	—
	Shock Absorber			—	RS999324
2006-00	All				
		2½"	0"		
	Left			RS999923	—
	Right			RS999931	—
	Shock Absorber			—	RS999040

^[254] Rear kit, required to level the rear to the front height.